





SPARE PARTS LIST

Mod.PPK.RIB-12V[2000W]1P3,1S/PLT[2+KY]

NO.	Part Name	Specifications	Qty
1	Motor	306	1
2	Start switch	684-1261-212-17 CE	1
3	Start switch line	L=100mm 16 ²	1
4	Insulation sheath	L10-16-32	2
5	Hexagon flange self-tapping screws	M6×10	2
6	Valve block	T40-2	1
7	Check valve	DF08-02	1
8	Solenoid valve	ZSV08-20	1
9	Solenoid valve coil	13372XY(DC 10V)	1
10	Pipe joint	G1/2"	1
11	Combination pad	G1/2"	1
12	Overflow valve assembly	SKS-YL-03	1
13	Plug	G3/8"	2
14	Combination pad	G3/8"	2
15	Gear pump	CBK-F3.2	1
16	Coupling	SKS-LZQ-01(L=45.5)	1
17	Socket head bolt	M8×85	2
18	Spring pad	M8	2
19	Return pipe	Φ10×100	1
20	Suction pipe	XYG-SL-03-02(55×30)	1
21	Strainer	SKS-LW-01(Φ62.5)	1
22	Magnet	5×20	1
23	Tank		1
23A	Tv=6,0 L Ev=4,0 L	L=180x180x196 mm	
23B	Tv=8,5 L Ev=6,0 L	L=180x180x275 mm	
23C	Tv=11,0 L Ev=8,0 L	L=180x180x355 mm	
23D	Tv=13,8 L Ev=10,0 L	L=180x180x440 mm	
23E	Tv=16,0 L Ev=12,0 L	L=180x180x520 mm	
24	O-ring	110.49×5.33	1
25	Respirator	SKS-HXQ-01(G3/8")	1
26	O-ring	15×2.65	1
27	Hexagon flange screws	M5×12	4
28	Motor guard casing	SKS-FHZ-01	1
29	Tie	10×650	1
30	Remote control (with key)	T2(3×1.5 ²)	1
31	Remote control's bracket	SKS-KZ-01	1
32	Fuse assembly	3A	1
33	Yellow cable assembly	1×0.75 ² L=5cm	1
34	User manual	PPK Instructions	1